

Turbo 7 MHz for the Sony HB-F700P/D MSX-2 Computer

Original by: Bas Kornalijnslijper

Translated by: Bart Hamer



Warning:


The most important part in the computer is the printed circuit board (PCB). Parts can be replaced, but not the PCB. Do not try to unsolder the parts, but cut them loose and then remove the solder pins. The use of IC sockets is recommended.

Upgrade package contents:

- Completely pre-assembled expansion board
- 40-pin IC socket
- Switch with led
- Resistor array (2K2)
- Insulating material (shrink tubing)
- Thin wire



The Sony HB-F700P/D MSX-2 computer.



The contents of the upgrade package.

Installation:

- Remove the cover (4 screws).
- Remove the disk drive (2 screws and 2 cables).
- Remove the video PCB (5 screws and 7 cables).
- Remove the bottom plate by loosening the screws slightly, after which it can be slid backwards (9 screws).
- Remove IC14 (Z80).
- Remove the resistor array RB1 (near the keyboard connector). Do not remove any modifications!
- Remove FB301 on the video PCB.
- Solder the new resistor array (2K2) in place of RB1 (note pin 1).
- Place the 40-pin IC socket in place of the IC14 (Z80).
- Place the Turbo 7 MHz expansion board in the IC socket.
- Make a connection between IC16 (74LS00) pin 10 and one of the free diodes on the Turbo 7 MHz expansion board.
- Mount the switch with LED in the front, the top cover or another place of your choice.
- The red or white wire is the positive side of the LED.
- The brown or black wire is the negative side of the LED.
- The orange/yellow or gray/purple wire pair is for the switch.
- Insulate the solders with a piece of shrink tubing.

Testing the Turbo 7 MHz:

The operation of the Turbo 7 MHz can be tested with the following BASIC test program:

```
10 FOR I=1 TO 100  
20 FOR J=1 TO 100: PRINT J;: NEXT J: NEXT I
```